

# CASEGOODS CARE & MAINTENANCE

CHERRYMAN's finish provides superior strength with enhanced stain and mar resistance for easy maintenance. However, care must be exercised whenever cleaning materials constructed of wood. Certain precautions will keep new furniture looking new:

- Dust all surfaces on a regular basis with a soft damp cloth, in the grain direction; do not use spray polishes or those containing silicone
- Lift all objects when moving ; never drag objects across the finished surface; sharp metal objects such as keys, spring binders and briefcase hinges should be kept from contacting the finished surface
- Wet objects should be placed on coasters; use a desk pad for writing
- Bottoms of items like flower vases and desk accessories should be protected
- Contact with certain plastics may result in discoloration and finish damage
- Use of felt pads under electronic equipment is recommended
- Furnishings exposed to ultraviolet rays may change color

CHERRYMAN's hardware is selected for easy maintenance. Certain precautions will help to keep these items looking new:

- Lubricate the housing and ball bearings of drawer suspensions every six months with a high quality petroleum jelly type lubricant
- Use a window type cleaner, sprayed onto the cloth, to clean pull hardware
- Furniture settles over time, to ensure correct drawer alignment, check unit is level and adjust glides as required