

AMBER


Assembly Instructions

CHERRYMAN


A324 Return Shell

A304 Return Shell


Ⓐ $\phi 15 \times 33$ 6(PCS)




Ⓑ $\phi 8 \times 30$ 6(PCS)




Ⓒ $\phi 22 \times 27$ 4(PCS)




Ⓓ $\phi 50$ 2(PCS)




Ⓔ $100 \times 50 \times 3$ 2(PCS)



Ⓕ $\phi 4 \times 20$ 12(PCS)




Ⓖ $\phi 3.5 \times 16$ 32(PCS)




Ⓗ $\phi 15 \times 1$ 8(PCS)



Ⓘ $\phi 15 \times 12$ 2(PCS)



Ⓙ $60 \times 30 \times 30$ 4(PCS)



Ⓚ $\phi 8$ 2(PCS)



Ⓛ $\phi 6 \times 13$ 2(PCS)








AMBER

Assembly Instructions

CHERRYMAN

A324 Return Shell

A304 Return Shell



AMBER

Assembly Instructions

CHERRYMAN

A324 Return Shell

A304 Return Shell

